

Engine Product Designation
D4-300D-F

Service activity	Action	
S At 12 months or 400 hours whichever occurs first		
Transmission, oil strainer, inner	Replace	●
Transmission, metal strainer, in shift valves	Clean	●
A Every 12 months or 200 hours whichever occurs first		
Check software status	Inspection	●
Engine oil and oil filters	Replace	●
Coolant level and antifreeze mixture	Inspection	●
Drive belts	Inspection	● / ○
Air filter	Replace	●
Fuel pre-filter and fuel fine filter	Replace	●
Seawater filter	Clean	● / ○
Anode, protection system	Inspection	● / ○
Impeller, seawater pump	Inspection	● / ○
Crankcase ventilation filter	Replace	●
Seawater inlet	Clean	●
B Every 12 months or 400 hours whichever occurs first		
Exhaust hose	Inspection	●
Transmission, oil and filter	Replace	●
Transmission, oil strainer, outer	Replace	●
Corrosion protection (space between IPS-housing and clamping ring)	Inspection	●
C Every 24 months or 400 hours whichever occurs first		
Impeller in seawater pump	Replace	●
D Every 48 months or 800 hours whichever occurs first		
Drive belts	Replace	●
Compressor oil	Replace	●
Transmission, metal strainer, in shift valves	Clean	●
Belt Tensioner, Belt Pulley, Idler pulley bearings	Inspection	●
E Every 1200 hours		
Propeller shaft seals	Replace	●
Magnet in oilsystem, lower gear	Clean	●
Exhaust plate	Inspection	●
F Every 48 months or 2000 hours whichever occurs first		
Coolant	Replace	●
Sea water pump overhaul	Replace	●